



USER MANUAL  
사용자 메뉴얼

2018 EDITION  
**nuke9**

**7.1 SURROUND SOUND GAMING HEADSET**  
UP TO 7.1 SPEAKER CHANNELS ANGLE AND POSITIONING



**THE ULTIMATE 7.1 GAMING HEADSET**

2018 EDITION

**nuke9****7.1 SURROUND SOUND GAMING HEADSET**  
UP TO 7.1 SPEAKER CHANNELS ANGLE AND POSITIONING**DRIVER SPECIFICATIONS**

Driver Diameter: 50mm  
Frequency Range: 20 – 20KHz  
Impedance: 20 $\Omega$   
Sensitivity: 115dB $\pm$ 3dB  
Output Power: 20mw

**MICROPHONE SPECIFICATIONS**

Mic Impedance: <2.2K $\Omega$   
Sensitivity: -43  $\pm$ 2db  
Frequency range: 20-16KHZ  
Directivity: Omnidirectional

**NUKE-9 FORM FACTOR**


Ear Cushions: Vegan Leather  
Wire length: 2.2M $\pm$ 3CM  
Wire Material: PVC  
Chassis Materials: ABS+Manganese Steel  
Connector Type: USB  
OS requirement: WinXP/Win7/Win8/Win10  
Net weight: 385g  
Overall Dimension: 208 x 186 x 107 MM

## KNOWING YOUR NUKE 9



1. Adaptive head beam
2. LED light
3. Microphone
4. Volume up/down

02



5. LED ON/OFF
6. 3D Sound ON/OFF
7. Microphone mute/unmute
8. Speaker mute/unmute



## NUKE 9 SOFTWARE TOOL INSTALLATION

Connect the headset into your PC/Laptop using the USB cable from the headset into the available USB slot on your PC/Laptop. Ensure it is connected before proceeding unto the next step of installation to avoid installation errors.

Note: In order to ensure the headset receives enough power, please do not connect the USB via USB HUB.

To use the powerful gaming function, users need to install and execute the gaming software tool. Insert the CD driver from the package into your CD ROM drive, then run the installation software program. Click Install and choose your language, after installation is completed, you might be asked to restart your PC, please do so before you can use the software fully.

## SOFTWARE GUIDE



Click "EQ ON" to enable/disable EQ.  
Click "3D ON" to enable/disable 3D sound effect.



Click "MIC" to control volume.  
Click "BOOST" to enable the microphone boost.  
Click "MUTE" to enable/disable mute or unmute.



Click "EFFECT" to enable/disable environment effects.  
Click an environment effect button to choose an environment effect.



Click "VIRTUAL 7.1" to enable/disable 7.1 virtual speaker.  
CW: The virtual speakers rotate clockwise slowly.  
CCW: The virtual speakers rotate counter clockwise slowly.  
Reset: Reset the location of virtual speakers/virtual listener to default.

**Save:** You can save your setting in .INI format files.

**Load:** You can load .INI format files which you have saved.

After settings are applied, you can play music, movie and games.

**NOTE:** The NUKE 9 controller works independently of the driver. For the operation of 3D sound effect, please switch ON/OFF either by the controller or the driver.

**Safety Notice:** In order to protect your eardrum, please turn down the volume before you wear the headset, and raise it slowly to a comfortable level after you wear it.

2018 EDITION

# nuke9

7.1 SURROUND SOUND GAMING HEADSET  
UP TO 7.1 SPEAKER CHANNELS ANGLE AND POSITIONING

## 드라이버 스펙

드라이버 크기 : 50mm  
주파수 범위 : 20 ~ 20KHz  
임피던스 : 20 Ω  
민감도 : 115dB ± 3dB  
출력 : 20mW

## 마이크 스펙

마이크 임피던스 : < 2.2K Ω  
민감도 : -43 ± 2db  
주파수 범위 : 20 ~ 16KHz  
방향성 : 전방향성

## NUKE-9 기타 사항

이어컵 : 비건 레더  
유선 길이 : 2.2M ± 3CM  
유선 재질 : PVC  
헤드셋 재질 : ABS + 강화 메탈  
연결 방식 : USB  
OS : Windows XP/Win7/Win8/Win10  
무게 : 385g  
전체 크기 : 208 X 186 X 107 MM

## NUKE-9 헤드셋



### NUKE-9 소프트웨어 설치

- 헤드셋을 컴퓨터의 USB 포트에 연결
- 소프트웨어 설치시 USB 분리 금지

참고 : 충분한 전류의 공급을 위해  
헤드셋을 USB 허브를 통해 연결하지 말고,  
직접 컴퓨터에 연결을 권장

소프트웨어 CD는 포함되어 있습니다.

소프트웨어 다운로드 사이트

[http://www.dareum.co.kr/#support\\_download](http://www.dareum.co.kr/#support_download)

1. 헤드 고정 빔
2. LED 라이트
3. 마이크
4. 볼륨 증가/감소
5. LED On/Off
6. 3D 사운드 효과 On/Off
7. 마이크 무음/무음해제
8. 스피커 무음/무음해제

## 소프트웨어 가이드



"EQ ON"을 클릭하면 EQ 활성화/비활성화  
 "3D ON"을 클릭하면 3D 사운드 이펙트  
 활성화/비활성화



"MIC"을 선택하면 볼륨 조정  
 "BOOST"를 선택하면 마이크 부스터 기능 활성화  
 "Mute"를 선택하면 무음기능 활성화/비활성화



"EFFECT"를 선택하면 환경 효과 활성화/비활성화  
 환경 효과를 선택할 경우, 환경 효과 버튼을 클릭



"VIRTUAL 7.1"를 선택하면, 7.1 가상 스피커 기능  
 활성화/비활성화  
 CW : 가상 스피커가 시계방향으로 서서히 돌아가는  
 효과  
 CCW : 가상 스피커 반시계방향으로 서서히  
 돌아가는 효과  
 Reset : 최초 설정으로 리셋

저장 : 설정을 .INI 파일 형식에 저장가능  
열기 : 저장한 .INI 파일을 불러서 사용 가능

설정 후 음악감상, 영화, 게임에 사용 가능

**참조 1:**

Nuke9 컨트롤러는 드라이버와 독립적으로 작동하며, 3D 사운드 효과의 작동을 위해 컨트롤러 또는 드라이버의 On/Off 스위치를 사용하면 됩니다.

**참조 2 :**

귀의 보호를 위해 사용 전 볼륨을 낮추고 사용 중에 천천히 볼륨을 올려야 합니다.

인증 받은 자의 상호 : 주식회사 다름 인터내셔널 (Dareum International Co.,Ltd.)

기기의 명칭(모델명) : 헤드셋 (Nuke9)

제조년월 : 별도 표기

제조사 : Sonic Gear Lab

제조국가 : 중국

인증 번호 : MSIP-REI-DRu-Nuke9

전화 번호 : 02-2219-5447